








# Discovery 2

## Assembly Instructions




**Step 2** Choose an area that is flat and free of sharp objects to avoid rip or puncture in the tent. Unpack the tent and all of its parts. Spread tent out flat on the ground, floor side down.



Unfold the pole carefully, seat each section into place, and ensure that each pole section rests firmly against the neighboring sections.

**Step 2** Insert the poles into the pins located on the rings at the corners of the tent.



**Step 3** Flex the poles into an upward position to raise the tent. Clip the hook at the center of the top roof to the intersection of two poles and clip the rest hooks to the poles.




**Step 4** Unfold the fly. Place the fly over the tent and attach the hooks on the fly to loops at the tent corners. Adjust the fly and pull the tent taut.



### TENT CARE TIPS

- Care**
  - \*Before setting up the tent, clear away sticks, rocks and other debris that may damage the tent floor.
  - \*Keep the poles clean and free of dirt, sand and salt.
  - \*Clear the tent after each use, air dry completely before storing.
  - \*Fold the poles from the center to the end to keep the cord elastic.
  - \*Repair it in time when damaged.
- CLEANING**
  - \*Avoid machine wash to maintain waterproof performance.
  - \*Wipe the soiled areas gently with a sponge, using lukewarm water.
  - \*Do not use hot water, bleach, dish washing liquid, fabric softener or presoaking products.
- STORAGE**
  - \*Make sure the tent is clean and dry before storing.
  - \*Store the tent in a dry and cool place.
  - \*For long-term storage, it is recommended to take the tent out regularly to clean and dry it.

**Step 5** Stake down tent by inserting tent stakes through the pin ring at each corner of the tent. Hammer stakes into ground at a 45° angle, by using a hammer or mallet. Make sure to pull the tent out even and tight.





**Step 6** Guy lines are attached to the fly for additional stability. Extend the guy lines and place loop over stake. Stake to the ground and adjust the slider to make guy lines tight.



**Features** Spacious round top; stable construction, easy to set up; breathable mesh inner; flexible dual door.



## component list



Customer Service Hotline: